



What are the tabletops made of?

The tabletops are made of 4 mm thick tempered Float glass. They are resistant to scratches, moisture, mechanical damage, and temperatures up to 250°C; however, a trivet is recommended for hot cookware. The smooth, elegant surface is easy to clean and suitable for dining rooms, offices, and commercial spaces. For printed tabletops, avoid prolonged exposure to strong sunlight to prevent fading.

Before starting installation

Make sure the table is stable, level, and free of any looseness, and that the surface underneath is clean and dry to avoid damaging the glass. For larger sizes (e.g. 100×50 cm or more), the tabletop should have additional central support -such as a brace, frame, or fifth foot—to prevent stress and possible cracking.

Step-by-step instructions

1. Thoroughly clean the surface where the tabletop will be placed - it should be dry, smooth, and free of dirt. 2. If you plan to attach the included pads, also clean the underside of the glass to remove dust and grease for proper adhesion. 3. Stick the pads in the corners of the tabletop and, for larger sizes, add one or more in the center to improve stability and prevent cracking. 4. Carefully place the tabletop onto the prepared surface with the pads facing downward.

Cleaning and maintenance

Clean the panel with a soft cloth and a mild cleaning agent, such as glass cleaner. Avoid using aggressive chemicals or sharp tools to prevent damage to the surface.

IMPORTANT! Take precautions when using the product.

Take special care when disposing of this product. It is made of glass, so handle with caution to avoid breakage or injury. Do not place it in areas exposed to strong vibrations that could cause it to fall. Install only on a stable, prepared surface using the included mounting elements. The tabletop has polished edges, making it smoother and safer to touch. However, if small children are present, we recommend adding corner protectors (e.g. silicone quards) to prevent accidental bumps. The set includes small parts (e.g. pads) that may pose a choking hazard - keep them out of reach of children. If the glass becomes damaged (e.g. cracked), stop using the product immediately. Always lift and move the tabletop by its edges, not by any accessories or mounting elements. Failure to follow these guidelines may result in damage or injury.







